PSEFI October 8, 2015


Professional Surveyors Educational Foundation, Inc.

Platting and "*Retro*spect" Workshop

Building on the Strength of our Past









































Generally speaking, roadways fall under two classifications





Now a quick word on R.O.W. Dedication

If the R.O.W. is not sufficient, you will be required to dedicate...




Dedication is a fancy term for the land necessary to complete the R.O.W. widening; which may come this year, or further down the "road."

Let's look at a quick example...


Let's say you want to replat several lots along a major thoroughfare.

80' R.O.W. to be Widened to 100'



The only issue is, this thoroughfare is classified as to be widened.

If this is the case, then the person developing is required to dedicate ½ of the remaining width along their portion of the property that fronts the roadway...





In other words, <u>your</u> development triggers the dedication requirement.

PSEFI: Transportation Panel

Professional Surveyors Educational Foundation, Inc.

- Amar Mohite
 Division Manager of Transportation Planning,
 City of Houston
- Fred Mathis, P.E.
 Manager of Planning & Development Harris
 County

Jesse Cooper
 Director, Map Survey & Utility Section,
 ROW Division, TxDoT

